





## Juiced Riders / ODK U500 V3 / Quick Setup Guide


1



2



3




4

Lift the bike out of the box and deploy the kickstand.


The bike should only be lifted by two or more persons.




**Do not remove the Foam on the Handlebar until Step 8**




**5**




Loosen the Quill Bolt with the 6mm Hex Wrench. Turn the Handle Bar clockwise and towards the front. Tighten the Quill Bolt.



**6**




Loosen the 2 Handle Bar Clamp Bolts. Flip the Handlebar upward as shown. Tighten the 2 Handle Bar Clamp Bolts to lock the new Handlebar position. The bolts should be very tight (20 Nm).



**7**

The left and right pedals are marked "CR-L" and "CR-R".




Install the pedals with the 6mm Hex Wrench.


The right pedal goes on the right Crank arm. The left Pedal goes on the left Crank Arm.



The Left Pedal is reverse threaded.




**8**



**9**

**Charge the battery completely.**


Locate the Charging Port on the bike. Slide the Charging Port's cover to the side. Insert the Charger Connector into the Charging Port.



**10**

**How to control the bike:**


**Turn on the battery power.**



**Twist the shifter to change gears.**

**Twist the throttle to send power to the motor.**

**Use the brake levers to slow down or stop.**



**Note:** The motor and shifter are independent systems.